

# GEN4 & ATP Polaris Winch Mount

## Winch Mount

PART # 100430

### Kit Components:

Qty	Part Description
1.....	Winch Mount
1.....	Fairlead Bracket
6.....	1/4-20 U-Nuts (D)
6.....	1/4-20 x 1.25" HH Bolt (E)
6.....	1/4" Flat Washers (F)
2.....	5/16-18 x 1.00" HH Flanged Bolt (G)

## INSTALLATION INSTRUCTIONS:

1. Loosen (do not remove) the two upper front bolts (A) of the ATV's brush guard.
2. Remove the six original Phillips head screws (B) retaining the side plastic shrouds and discard.
3. Remove the two original upper rear bolts (C) of the ATV's brush guard and discard.
4. On the plastic shrouds remove the OEM U-Nuts and replace them with the Supplied black threaded U-Nuts (D).
5. The ATV's brush guard is loose and has adjustment so that you can move the brush guard in and out to line up all eight holes.
6. Place the mount in position and attach the mount with the top holes first using the supplied 5/16" bolt (G) "Do not tighten".
7. Once the two top bolts are started you can reassemble the plastic shrouds using the supplied bolts (E) and washers (F) "Do not tighten".
8. Once all eight bolts are started you can tighten them.
9. Assemble your winch and the Fairlead Bracket to the Mount using the hardware that was supplied with your winch. Use the required (2) or (4) holes needed to mount your winch and fairlead bracket as shown in the Picture to the left.
10. Using the instructions provided with your Winch wire accordingly.

