YAMAHA GRIZZLY 550/700

Winch Mount

PART #100610

Rev D

| Kit Components: | | |
|-----------------|------|---|
| Item # | Qty. | Description |
| 1 | 1 | Winch Mount (100610-MP) |
| 2 | 1 | Hardware Kit (HK-025) |
| 2.1 | 2 | 3/8"-16 x .750" Flange Bolt GR5 |
| 2.2 | 1 | 3/8"-16 x .750 Short Neck Carriage Bolt |
| 2.3 | 2 | M10 x 1.25 x 20mm Hex Bolt GR8.8 |
| 2.4 | 2 | 7/16" Lock Washer |
| 2.5 | 2 | 3/8" Nylock Jam Nut |
| 2.6 | 6 | 3/8" SAE Flat Washer |

Notice

Torque bolts to ANSI Specs (or OEM specs if applicable), unless otherwise stated. After the first use and at the start of each season, check torque.

Note: Make sure all hardware needed to complete this mount is in the package. Thoroughly read through and understand the instructions before installing.

Installation Instructions

NOTE: If the winch has a clutch end with a large diameter, replace the 3/8" flange bolt on the clutch side of the mount with the supplied carriage bolt [A]. This provides clearance for the bottom of the clutch housing. Insert the carriage bolt into position before mounting the winch to the mount. See Figure 1.

- Attach the Winch and Fairlead to the winch mount
 using the hardware supplied with the winch.
 See Figure 2.
 - Once the Winch and Fairlead are assembled, place the winch into the OEM mounting location. Secure it to the frame with the hardware provided. Refer to Figures 1, 2, and 3.

Note: For the rear M10 bolt, you may only need one of the 3/8" washers along with a 7/16" lock washer.

- 3. OPTIONAL: You may choose to mount the contactor to the Mount Plate using the hardware supplied with your contactor. See **Figure 2.**
- 4. Follow the instructions provided with your winch to complete the wiring.











