JOHN DEERE GATOR XUV

Winch Mount

PART # 100860

Hardware Kit: HK-097, HK-031

Kit Components:

Qty. Part Description

1..... Winch Mount Plate

2..... Winch Mount Spacer Plate

4...... 3/8"-16 x 1-1/4" Hex Flange Bolt (HK-097)


1...... UTV Mini Rocker Kit (HK-031)

INSTALLATION INSTRUCTIONS:


- 1. Detach front bumper tubes by removing 2 pull pins and 2 bolts (A). (See Figure 2)
- Bolt the roller fairlead to your fairlead bracket. Then bolt the winch and roller fairlead assembly to the winch mount using the hardware included with your winch (as shown in Figure 1).


Note: Follow instructions included with your winch for attaching the cable and wiring. The large holes in the back of the winch mount plate provide access for wiring.

- 3. Place winch assembly into position as in Figure 3. Using the supplied 3/8" hardware, bolt the winch mount plate and spacers to the frame (B) as shown in Figure 4.
- 4. To make install easier, bolt the spacer by running lower bolt through frame and mount, then rotate up and install remaining hardware. (See Figure 4)
- 5. See bold note on Page 2 for wiring instructions.
- Reattach front bumper tubes using pull pins and bolts removed previously.



"Figure 4" Spacer Install





"Figure 2" Bumper Removal



"Figure 3" Mount Plate Install

WIRING INFORMATION

1. For contactor location see "Figure 5". There is no particular location on this machine, anywhere under the hood is best.


Note:

The wires will need to be switched for this machine. The longer wires (Blue/Yellow) will be used to go from the battery to the contactor. The shorter wires (Black/Red) will be used to go from the winch to the contactor.


- 2. Mini-Rocker Switch Hardware kit. This allows you to mount your usual handle bar mounted switch to almost any desired location.
 - a. Remove handlebar mount hardware from the switch.
 - b. Locate desired mounting location
 - c. Mark and drill two switch holes through dash using switch housing as a template
 - d. Drill a 3rd hole for the switch wiring.
 - e. Assemble per Figure 7.
- 3. Find a location that suits your purposes for the mini-rocker switch and hand remote plug-in socket.



"Figure 5" Contactor Location (Under Hood)



"Figure 7" Mini-Rocker Mounting



"Figure 6" Battery Location (Battery is located under passenger seat.)



